


ECR UTILITY

9 Pin Serial Port Connector

PC to ECR cable



UP-3300 9 way D type Female



PC 9 way D type Female

Function	Pin No.		Pin No.	Function
DCD (Data Carrier Detect)	1	}	1	DCD (Data Carrier Detect)
DTR (Data Terminal Ready)	4		4	DTR (Data Terminal Ready)
DSR (Data Set Ready)	6		6	DSR (Data Set Ready)
RX (Receive Data)	2			TX (Transmit Data)
TX (Transmit Data)	3			RX (Receive Data)
GND (Signal Ground)	5			GND (Signal Ground)
RTS (Request To Send)	7	}	7	RTS (Request To Send)
CTS (Clear To Send)	8		8	CTS (Clear To Send)
RI (Ring Indicator)	9	Not Used	9	RI (Ring Indicator)